

# Oil Care Kit

- for the maintenance of oiled wood surfaces



- For the maintenance of all oiled wood floors
- Simple application
- Certified by IBR

## Product info

### Maintenance Paste

Container: 400 ml.

Consumption: 60-80 m<sup>2</sup>/400 ml.  
(For UV oiled floors approx  
120 m<sup>2</sup> /400 ml.)

### Intensive Cleaner / Natural Soap

Container: 750 ml.

Consumption:  
Lacquer Care Spray 60 m<sup>2</sup>/L



## Application area

Maintenance Paste is supplied in a very handy tube. Because of its texture the paste is easy to apply. Maintenance Paste is used for the maintenance and preservation of all oiled wood surfaces. The paste is especially suitable for industrially oiled wood floors – herunder also UV-oiled floors. Maintenance Paste natural is suitable for naturally oiled wood, whereas Maintenance Paste white is used for white oiled wood.

## Result

The Paste provides the floor with a dirt- and water resistant surface which is very hard-wearing.

## Application

Maintenance Paste may be applied and buffed manually with a white pad or with a polishing machine.

## After care

Not required.

## Maintenance and cleaning

Maintenance cleaning with Natural Soap. Basic cleaning with Intensive Cleaner.

# Oil Care Kit

- for the maintenance of oiled wood surfaces



## All in one box...

- everything you need to clean and to rejuvenate your oiled wooden floor

Intensive Cleaner is a unique ready-to-use-spray for the all-round cleaning of all interior wood work independently whether the surfaces are oiled or waxed. It provides an excellent cleaning and removes the most difficult dirt, grease and stains and it is fast and simple to apply.

Maintenance Paste is for the re-freshening and maintenance of oiled wood floors. The Maintenance Paste is also especially suitable for UV-oiled floors.

Natural Soap is ideal for cleaning and maintenance of oiled or waxed surfaces. Natural Soap is a purpose-made quality soap, which due to its nourishing properties quickly closes the pores of the wood and protects against dirt and penetration of liquids.

**Please notice! Risk of self-ignition: Due to the risk of self-ignition it is important that oil wetted cloths are soaked in water and disposed of in a tightly closed container after use.**

## How to do...

Oiled floors should be regularly maintained - normally once a year, but more often when it comes to floors exposed to extremely hard wear.

- 1 Before use shake bottle of Intensive Cleaner carefully. Spray the Intensive Cleaner onto the surface. Leave solution to dissolve stain and dirt etc. Wipe surface dry with a firmly wrung cotton cloth. Leave surface to dry.
- 2 Apply thin coat of Maintenance Paste onto 1-2 m<sup>2</sup> floor at the time with white polishing pad or cotton cloth. Use floor machine for distribution of Maintenance Paste for large areas.
- 3 Make sure that the Maintenance Paste is polished uniformly into the wood. Buffing continues until wood appears saturated and silk-mat. Apply more paste if necessary.
- 4 If a very mat finish is required, make buffing with cotton cloths under polishing pad. Let surface rest for 4 hours. Do not expose floor to water for 48 hours after finishing

### Regular cleaning

Natural Soap is ideal for the cleaning and maintenance of all oiled or waxed wood surfaces.

Natural Soap white is shaken carefully before use. Spray the Natural Soap on the surface and wipe the surface with a cotton cloth.

**Please notice!** Particularly dirty floors or stubborn stains may be removed with Wood Cleaner or Spot Remover.



### The box contains:

400 ml Maintenance Paste | 750 ml Intensive Cleaner  
750 ml Natural Soap